



Owner's Manual

TC-300 & 310

COMBINATION BODIES



TRUCKCRAFT CORPORATION

5751 Molly Pitcher Hwy. S.

Chambersburg, Pa. 17201

Tel. 800 / 755 - 3867

Fax. 717 / 375 – 2975

E-Mail Sales@TruckCraft.com

WWW.TruckCraft.COM



"WHERE WORKMANSHIP IS EVERYTHING"

TC-300/310 SERVICE DUMPER OPERATING INSTRUCTIONS

This Dump Bed, like any product, will perform and last depending on how it is used and cared for.

Below are some safety, operating and maintenance guidelines for using the Dumper:

1. **NEVER** exceed the manufacturer's gross vehicle weight rating.
2. **NEVER** exceed the rating of the truck axles and tires.
3. **ALWAYS** load the bed keeping as much of the load as possible centered over or forward of the rear axle.
4. **NEVER** exceed the structural capacity (12,000 lbs.) of the Dumper. Structural capacity means the maximum weight the Dumper will carry and dump with some margin of safety. This does not mean that your truck can carry 12,000 lbs. See GVWR of truck.
5. **ALWAYS** operate the Dumper on level ground.
6. **ALWAYS** open the tailgate prior to raising the Dumper when it is loaded.
7. **Do Not** place anything on top of the cabinets. Damage will occur when the Dumper is lowered if anything is left on top of the cabinets.

8. **Always** store the remote control in a location that assures that no object can come in contact with the raise button unintentionally.
9. **Always** keep all personnel clear when raising and lowering the Dumper.
10. **Before** raising the Dumper, check for adequate overhead clearance. Be alert for overhead electrical wires.
11. **Do Not** tilt the Dumper when loaded until the bottom of the tailgate has been released. The top of the tailgate **should not** be opened with a load against it.
12. **ALWAYS** use the service safety prop when doing service or repairs on the Dumper
13. **ALWAYS** empty the bed prior to using the safety prop and doing any service or repair work on the Dumper.
14. **Lubricate** the following locations every 3 to 6 months depending on use:

Rear dump body pivots	(2 places)
Lower tilt cylinder pivot	(1place)
15. **Check** hydraulic fluid level every 6 months. If additional fluid is required, add hydraulic fluid or Dextron Automatic Transmission Fluid. **Caution:** do not overfill.

DO NOT attempt to repair this Dump Body yourself unless you have experience working on dump beds and are familiar with the hazards involved. For all purposes of safety, please take your equipment to the dealer from which it was purchased for all repairs and service.